

Gemini 16ch radiomics – US versions

Channels & Frequencies

The 16 UHF radiomic frequencies preset into the Gemini radiomics that are distributed in the US.

NOTE - when using two radiomicrophones it is important to select two frequencies, which are more than 0.5Mhz apart to avoid interference between the two transmitters

CHANNEL 1	790.375 MHz
CHANNEL 2	791.125 MHz
CHANNEL 3	792.125 MHz
CHANNEL 4	793.250 MHz
CHANNEL 5	794.250 MHz
CHANNEL 6	795.125 MHz
CHANNEL 7	796.250 MHz
CHANNEL 8	797.375 MHz
CHANNEL 9	798.375 MHz
CHANNEL 10	799.875 MHz
CHANNEL 11	800.875 MHz
CHANNEL 12	801.625 MHz
CHANNEL 13	802.750 MHz
CHANNEL 14	803.875 MHz
CHANNEL 15	804.750 MHz
CHANNEL 16	805.375 MHz